




# Floor Scales Troubleshooting Guide



**Helpful troubleshooting instructions for the following scale and product types:**

- Floor Scales
- Bench Scales
- Counting Scales
- Printers
- Railroad Scales
- Truck Scales



# Floor Scales Troubleshooting

By their nature, floor scales are one of the most abused pieces of equipment. Forklift loading, corrosive materials, heavy wash downs, dust, debris, overloading and hazardous areas are just a few of the tough environments floor scales have to perform in each day. Use these troubleshooting tips to ensure your floor scale is always operating at peak performance.

<b>Issue</b>	<b>Probable Cause</b>	<b>Solution</b>
<b>Inaccurate weights</b>	Obstructions, debris	Clean out around and under scale. Make sure no foreign objects are wedged under scale
<b>Inaccurate weights</b>	Uneven surface, uneven heights	Place scale on clean flat surface. Make sure all corners are evenly supported and not tipping back and forth
<b>Platform rigid and no oscillating</b>	Obstructions, debris	Clean out around and under scale; make sure no foreign objects are wedged under scale
<b>Platform rigid and not oscillating</b>	Broken suspension parts	Call for service
<b>Scale stays on zero with weight applied</b>	Broken or cut cable	Make sure load cell cable is undamaged. If equipped with quick disconnect, make sure cable is fully plugged in
<b>Weight display not returning to zero</b>	Obstructions, debris	Clean out around and under scale; make sure no foreign objects are wedged under scale
<b>Weight display not returning to zero</b>	Uneven surface, uneven heights	Place scale on clean flat surface. Make sure all corners are evenly supported and not tipping back and forth
<b>Weight display not returning to zero</b>	Defective load cell	Call for service

<b>Weight display unstable</b>	Excessive vibration	Dampen source of vibration with shock absorbing material (i.e. rubber mounting assembly)
<b>Weight display unstable</b>	Broken or cut cable	Make sure load cell cable is undamaged; if equipped with quick disconnect, make sure cable is fully plugged in
<b>Weight display unstable</b>	Defective load cell	Call for service